

# HAAS Lathe Cleaning Procedure

1. Clean all tools and place back into proper locations
2. From top to bottom, use the hand broom to brush all large shavings off machine onto the floor
3. Use rag to soak up oil and coolant
4. Sweep up shavings off of floor (including backside)
5. Vacuum all remaining shavings (on and off machine)
6. If oil or coolant is spilled on the floor mop around machine.
7. Scan 360 degrees around machine and repeat steps if necessary



**8. Dispose of refuse inside bin**